Ice age

Ice age is a game in which children are challenged to find the right head for each illustrated body. The rectangular wall game has a natural, modern frame made of birch plywood with a white painted front which compliments many environments.

Graphic colours Pantone no.

021C	170C	543C	691C	727C	4635C	Black

White

Play module | Ice age

| Article no.	Frame colour	Colour code	Size HxWxD	Mounting	Age	KG	
PP00704	White	RAL 9003	70x45x5,15cm	wallmount	2 - 8 years	5,7 KG	Birch Plywood, RVS, ABS, MDF

● Playable on one side

■ Playable on both sides

Play Module

■ PM^A   ● PM^B

Playable on one side   *Playable on both sides*

FM Frame

FM

## Required tools

Drill

4mm 2x

Fence mounted

FP^A   FP^B

Playtower mounted

PP

Play system mounted

PS

Play system of choice

Screws

S4   S9   S13   S16   S18   S19

25 mm   35 mm   50 mm   60 mm   22 mm   40 mm

IKC
INTERNATIONAL
KIDS
CONCEPTS

Play Module   ■ PMᴬ   ● PMᴮ

All the play modules needs to be mounted 40 cm above the ground. This is for the optimum play comfort.

40 cm

1.1 Play Module

S16

■ PMᴬ   ■ PMᴬ

Required tools

S16 ④ₓ   ■ PMᴬ   Drill

2.1 Play Module with FM Frame   ● PMᴮ

To put a playmodule on a FM frame, you should remove these slats.

● PMᴮ

2.2 Play Module install FM Frame   ● PMᴮ

S16   S4   ● PMᴮ   FM   Drill

4x   4x

● PMᴮ   FM

S16   S4

FM   ● PMᴮ

3.1 Play module ■ PM^A ● PM^B

To put a play module on a playsystem, you should remove these slats.

● PM^B or ■ PM^A

3.2 Play module on play system

● PM^B or ■ PM^A PS

PS

S18   S4

● PM^B or ■ PM^A

## Required tools

● PM^B or ■ PM^A PS

S18   S4

4x   4x

Play module ▪ PM^A ● PM^B

All the play modules needs to be
mounted 40 cm above the ground.
This is for the optimum play comfort.

40 cm

4.1 Install play module on play tower
Required tools

S9   S19   ▪ PM^A   PP

4x   4x

▪ PM^A

PP

S19   S9

PP PMA

5.1 Install FM Frame to play module ● PM^B

To put a playmodule on a FM frame,
you should remove these slats.

● PM^B

5.2 Install play module with FM frame on play tower
Required tools

S4   S13   S18   ● PM^B   FM   PP

4x   4x

4x

S18   S13   S4

● PM^B   FM   PP

● PM^B   FM   PP

Play module ■ PM^A ● PM^B

All the play modules needs to be
mounted 40 cm above the ground.
This is for the optimum play comfort.

40 cm

6.1 Install play module on fence
Required tools

S9　　S19　　■ PM^A　　FP^A

4x　　4x

S19　　S9

■ PM^A　　FP^A　　　■ PM^A　FP^A

7.1 Install FM Frame to play module ● PM^B

To put a playmodule on a FM frame,
you should remove these slats.

● PM^B

## 7.2 Install play module with FM frame on fence
Required tools

S4　　S13　　S18　　● PM^B　　FM　　FP^A

4x　　　　4x

4x

S18　　　　S13　S4

● PM^B　FM　FP^A

● PM^B　FM　FP^A

8.1 Remove the slats ● PM^B ◼ PM^A

To put a playmodule on a fence (FP^B),
you should remove these slats.

● PM^B or ◼ PM^A

8.2 Install play module on fence
Required tools

S18   S4   ● PM^B or ◼ PM^A FP^B

4x   4x

S19   S9

● PM^B or ◼ PM^A FP^A ● PM^B or ◼ PM^A FP^A